


# DC-CONTROLLER

## MU1000C – Configurator

### USER MANUAL

(Version 1.39)



## **Information about the user manual**

**IMPORTANT!** Please read this user manual very carefully before assembling and starting this device!

The user manual is a part of the delivery of this device, i.e. it should be made available to each and every person involved with the starting, maintenance or operation of the device. The device should be transported, mounted, started, maintained and operated only by Electro technical personnel.

The local specifications for the prevention of accidents as well as the general guidelines according to IEC 364 should always be followed!

The functional descriptions in the user manual correspond to those at the time of the publication. Technical changes can be carried out by the Eltek Valere Industrial GmbH without making any revisions or announcements. There is no responsibility for the constant revision of the operation manual.

The device complies to the EN- and VDE-standards applicable at the time of the publication. The CE symbol on the device confirms the conformation of the EU-guidelines 2006/95/EG (Low voltage directive) and 2004/108/EG (EMC directive).

The devices are delivered exclusively according to our delivery and sales conditions. Alterations in the technical details in this operation manual as well as the respective data sheets are reserved.

Complaints about the delivered goods should be made as soon as possible on receiving them along with the packing invoice as well as the information about the type, serial number and complaint.

Guarantee claims of the customer will not be entertained in the case of visible external influences (e.g. absent or loose screws, welding, loose sheets, etc.), that could be attributed to a non permitted opening of the device.

Eltek Valere Industrial GmbH does not undertake any responsibility for applications of the device, which have not been intended by the manufacturer. It is the responsibility of the final-consumer to take the necessary measures for the prevention of damage to personnel and to goods (see upper text section).

# DC-Controller MU1000C Configurator

User manual

Page 3 (58)

---



## Supplier:



ELTEK VALERE Deutschland GmbH  
GB Industrial  
Schillerstraße 16  
D-32052 Herford



+ 49 (0) 5221 1708-210  
FAX + 49 (0) 5221 1708-222  
Email [Info.industrial@eltekvalere.com](mailto:Info.industrial@eltekvalere.com)  
Internet <http://www.eltekvalere.com>

## IMPORTANT!

Repetition, copying and /or taking possession of this operation and maintenance manual, even in extracts, with electronic or mechanical means, requires the written, prior permission of the SUPPLIER.

©2009. ELTEK VALERE DEUTSCHLAND GmbH. All rights reserved.

# DC-Controller MU1000C Configurator

User manual

Page 4 (58)

---

## The current revision status of this manual is the following:

Revision: 03  
Date: 2009-06-24  
System: MU1000  
System voltage: 24/48/108/216VDC

Revision	Description of changes	Author	Date
00	New Layout	PS	19.06.2008
01	New Layout	PS	29.09.2008
02	Section 5.7 updated	RTH	2009-02-12
03	Section 8. "Input LCD characters" added, minor text modifications	PS/RTH	2009-06-24

## **Table of Contents**

<b>1. INTRODUCTION</b>	<b>7</b>
1.1 Requirements to start programming of MU1000C	7
<b>2. PROGRAM START</b>	<b>8</b>
<b>3. MAIN MENU ITEMS</b>	<b>9</b>
3.1 Main menu item – “File”	9
3.2 Main menu item – “Data”	10
3.3 Main menu item – “RS232”	11
3.4 Main menu item – “Help”	12
<b>4. GENERATE A PROJECT FILE</b>	<b>13</b>
4.1 New project file	13
4.2 Open existing project file	15
4.3 Read data from MU1000C	15
4.3 Read data from MU1000C	16
<b>5. CONFIGURATION REGISTERS</b>	<b>17</b>
5.1 Register – “Text”	17
5.2 Register – “Analog inputs and Shunts”	19
5.2.1 Analog inputs	19
5.2.2 Shunts	21
5.3 Register – “Digital inputs”	22
5.4 Register – “Thresholds”	23
5.5 Register – “Devices”	27
5.5.1 Device	27
5.5.2 INV	32
5.5.3 Rectifier	33
5.6 Register – “Outputs”	35
5.6.1 MU1000C	35
5.7 Register – “Modem/RS232”	37
5.8 Register – “Signal configuration”	41

# DC-Controller MU1000C Configurator

User manual

Page 6 (58)

---



<b>5.9 Register – “Battery”</b>	<b>43</b>
5.9.1 Value	43
5.9.2 Test	45
5.9.3 Tk	46
<b>5.10 Register – “Boost-/Manual charge/System test”</b>	<b>47</b>
5.10.1 Boost charge	47
5.10.2 Manual charge	49
5.10.3 System test	50
<b>5.11 Register – “Counter cell”</b>	<b>51</b>
<b>5.12 Register – “ MM1”</b>	<b>52</b>
<b>6. SEND NEW DATA TO MU1000C</b>	<b>53</b>
<b>7. SAVE PROJECT FILE</b>	<b>54</b>
<b>8. INPUT LCD CHARACTERS (ESPECIAL FOR CYRILLIC CHARACTERS)</b>	<b>55</b>
8.1. LCD character set	56
<b>9. NOTES</b>	<b>57</b>
<b>10. DATA TRANSMISSION ERROR / DATA TRANSMISSION ABORTION</b>	<b>58</b>

## **1. Introduction**

The MU1000C configurator is a program to change and adjust values of a MU1000C-unit. The values are changed using a PC and transmitted via serial interface RS232 to the MU1000C.


### ***1.1 Requirements to start programming of MU1000C***

To start with configuration of MU1000C via this program you have to check whether the following requirements are fulfilled:

1. MU1000C is switched on and the display shows the main menu
2. RS232 port is connected via a null modem cable (Sub-Min D 9-pole) to a free COM port of your computer
3. The transmission speed of the used COM port is set to 9600 Bps
4. The file MuConfV1\_xx.EXE (delivered on CD) has been saved in a specific directory on your hard disk

The software is tested with following operation systems: Microsoft® Windows 95®, Microsoft® Windows 98®, Microsoft® Windows 2000® +XP.

## 2. Program start



Click on MuConfV1\_xx.exe in the specific directory on your hard disc.


The picture on the left shows the main screen after starting the MU1000C-Configurator.

In the main menu bar you find following items:

- **"File"** for open/close/save/print project files
- **"Data"** to start the transmission of data to and from MU1000C
- **"RS232"** to check and change the baudrate and COM port for transmission cable
- **"Help"** with MU1000C version and registration code information

In the icon bar you find buttons for "Read data from MU1000C", "Write data to MU1000C", "Open project file", "Close project file", "Print configuration data" and "Exit".


The configuration values are arranged in 12 registers.





### 3. Main menu items

#### 3.1 Main menu item – "File"



*New Project* – generate a new project file

*Open* – open a saved project file

*Save* – save the changed project file


*Save as* – save the changed project file with another name

*Printer configuration* – set the default printer for printing the configuration data list

*Print* – print out the configuration data list


*Quit* – exit the program

**3.2 Main menu item – "Data"**




The screenshot shows the main menu of the MU1000C Configurator. The title bar reads "MU1000C Configurator Version 1.39.6". The menu bar includes "File", "Data", "B5232", and "Help". The "Data" menu is open, showing options: "Read MU1000C -> PC", "Write PC -> MU1000C", and "Exit". Below the menu bar, there are tabs for "Signal configuration", "Battery", "Boost-/Manual charge / System test", "Counter cells", and "MM1". The "Signal configuration" tab is active, showing fields for "Serial-No." (JJ000000-000.000), "Project", "MU Firmware" (Version 2.08), and "Path". There are also checkboxes for "Language MU1000" (English, German, Swedish) and "Logo line 1" (Eltek Valere, Number of characters: 16). A "Nominal voltage range" dropdown is set to "MU1000C-I (20V-80V)". A "Memo" text area is at the bottom. The status bar shows "InterfaceCOM1", "OK", "Cancel", and the date/time "24.6.2008 12:56:08".

Read MU1000C->PC – start data transmission from MU1000C to your computer




This screenshot shows the "Read MU1000C->PC" operation in progress. A progress bar is visible, and a small window displays "Transmission reading 1" with a progress bar. The status bar shows "InterfaceCOM1", "OK", "Cancel", and the date/time "24.6.2008 12:56:08".


Write PC->MU1000C – start data transmission from your computer to MU1000C



This screenshot shows the "Write PC->MU1000C" operation in progress. A progress bar is visible, and a small window displays "Transmission writing 1" with a progress bar. The status bar shows "InterfaceCOM1", "OK", "Cancel", and the date/time "24.6.2008 12:56:08".



### 3.3 Main menu item – "RS232"



During startup of the software a free COM port is automatically detected. In case of detection failures you can adjust the correct COM port manually.


**Comm. Port** – COM port on which the serial transmission cable is connected

**Baud Rate** – the default rate is 9600

**Data bits** – the standard value is "8"

**Stop bits** – the standard value is "1"

### 3.4 Main menu item – “Help”



This menu item shows the main service parameters of the actual configurator software and the online help:

Menu item – “Info”:


- Support address for questions to the used MU1000C-Hardware
- Support address for questions to the used configurator software
- Software version
- Serial number of configuration software
- Name of registered user

Menu item – “Help”:

- Direct help (in future)
- Explain different “catchwords” (in future)

## 4. Generate a project file

### 4.1 New project file




If you try to fill in data for MU1000C configuration before you opened a new project file or a saved project file you get the message: "Please open a file, new project or read data from MU1000!"

To generate a new project file select *File/New...*

Choose the *Nominal Voltage Range* of the MU1000C unit that you are using.

Confirm with "OK".



The window "Save as" will appear.

Give a name for the new project file.

☞ We recommend to use subdirectories named to order code for each new project.


The project file suffix is "mc1".

Old versions before V2.0 have the suffix "mcu".

You do not need to fill in the suffix, because the software will generate it automatically.

Confirm with "OK".

#### 4.2 Open existing project file




To open an existing project file select *File/Open...*


The window "File open" will appear.

Search for the right file in your harddisk subdirectories (suffix ".mc1" is preadjusted).

Click on the file name and confirm with "OK".



#### 4.3 Read data from MU1000C



To read data from MU1000C select  
Data/Read MU1000->PC...


The window "Data transmission PC <- MU1000C"  
will appear.

With "cancel" you stop the data transmission.



**5. Configuration registers**

**5.1 Register – “Text”**





*Serial no.* – the serial number of the MU1000C hardware is shown automatically in this line

*Project* – project file name  
You can change this name if you save the project file with “File/Save as...” with another name.

*Firmware* – firmware version of MU1000C processor software.  
The firmware version will be read out from the MU1000C during data transmission from MU1000C to PC.

*Path* – file path for your project file  
You can change this file path if you save the project file with “File/Save as...” in another subdirectory on your harddisk.





*Language* – choose the language that you usually use to display in the MU1000C.

The third language is customer specific. If you read from the MU1000C than you will see the language in the MU.

*Logo name line 1* – fill in your company name (max. 16 letters)

The logo name will appear in the main menu on MU1000C display.

*Logo name line 2* – fill in any statement or note (max. 16 letters)


The logo name will appear in the main menu on MU1000C display.

In the Logo lines you can also put in special characters like Cyrillic, to display in the MU1000C.

*Click on the right mouse button to get a LCD character set, than paste the string into the line.*

## 5.2 Register – “Analog inputs and Shunts”

### 5.2.1 Analog inputs



MU1000C Configurator Version 1.39.6

Registered for : Eltek Valere Indust

Signal configuration | Battery | Boost - / Manual charge / System test | Counter cells | MM1

Text | **Analog inputs** | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Analog inputs

MU 1000C

Input	Display	Text
1Vdc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	Udc1:
1Vdc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Vdc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	Idc1:
1Idc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	

Shunts

1Idc1	50	A
1Idc2	50	A
1Idc3	50	A

InterfaceCOM1 OK Cancel 24.6.2008 15:08:03

©2009, ELTEK VALERE DEUTSCHLAND GmbH.

On this page you are able to assign the designations for the analogue measuring inputs of MU1000C.

Following designations are possible for every measuring input:


**Display – Yes** – value is displayed on MU1000C display  
(use this selection if the measuring input is used)

**Display – No** – value is not displayed on MU1000C display (use this selection if the measuring input is not used)

**Text – User defined voltage and current measurement designations** – fill in your own measurement designation if you do not want to use predefined designators  
(max. 8 letters)

You can also put in specific characters such as Cyrillic, to display the text in the MU1000C (for details see section 8.)

Click the right mouse button to get a LCD character set, than paste the string into the line.



MU1000C Configurator Version 1.39.6

File Data RS232 Help

Registered for : Eltek Valere Indust

Exit

Signal configuration | Battery | Boost / Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Analog inputs

MU 1000C

Input	Display	Text
1Vdc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	1Udc1:
1Vdc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Vdc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	1Idc1:
1Idc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	

Shunts

1Idc1	50	A
1Idc2	50	A
1Idc3	50	A

BM1 Socket X1

Input	Display	Text
2Vdc1	<input type="radio"/> Yes <input checked="" type="radio"/> No	2Udc1:
2Vdc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	2Udc3:
2Idc1	<input type="radio"/> Yes <input checked="" type="radio"/> No	2Idc1:

Shunt

2Idc1	50	A
-------	----	---

InterfaceCOM1

OK

Cancel

25. 6.2008 09:50:41

Depending on the number of batteries the BM1-board appears on the display. The max number of battery banks which can be measured is 3. (to set the number see Register "Battery")  
The picture shows a battery count of 2.

5.2.2 Shunts

MU1000C Configurator Version 1.39.6

File Data RS232 Help

Registered for : Eltek Valere Indust

Exit

Signal configuration Battery Boost-/ Manual charge / System test Counter cells MM1

Text Analog inputs Digital inputs Thresholds Devices Outputs Modem / RS 232

Analog inputs

MU 1000C

Input	Display	Text
1Vdc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	Udc1:
1Vdc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Vdc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	Idc1:
1Idc2	<input type="radio"/> Yes <input checked="" type="radio"/> No	
1Idc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	

Shunts

1Idc1	50	A
1Idc2	50	A
1Idc3	50	A

BM1 Socket X1


Input	Display	Text
2Vdc1	<input type="radio"/> Yes <input checked="" type="radio"/> No	2Udc1:
2Vdc3	<input type="radio"/> Yes <input checked="" type="radio"/> No	2Udc3:
2Idc1	<input checked="" type="radio"/> Yes <input type="radio"/> No	2Idc1:

Shunt

2Idc1	50	A
-------	----	---

InterfaceCOM1 QK Cancel 25.6.2008 10:50:32

*Idc1* – set the correct shunt size connected to measuring input Idc1


 To measure the battery charge/discharge current you have to use Idc1 input because this input can handle positive and negative measurement values.

*Idc2* – set the correct shunt size connected to measuring input Idc2

*Idc3* – set the correct shunt size connected to measuring input Idc3

### 5.3 Register – "Digital inputs"

If you connect external signaling loops to MU1000C digital input interface you can configure every input (16 in total, 8 inputs from MU1000 and 8 inputs from external I/O-Board or DIG8) as following:



**Input no.** – number of used digital input

If you use the optional MU1000C-I/O board to increase the numbers of outgoing relay contacts you have to use the digital inputs on this board instead of the inputs on MU1000C hardware!

**Text** – fill in a error text (max. 16 letters)

This text will be used to show the signal change on digital input during operation in the error list and/or history list on MU1000 display.

**Break contact/Close contact** – MU1000C detects an error on the input if the input contacts are "open"/"close"

**Delay** – delay time for digital input error detection in sec.


You can also put in especial characters such as Cyrillic, to display the input text in the MU1000C.

You can click the right mouse button to get a LCD character set, than paste the string into the edit field.

The panel "I/O- or DIG8 inputs" appears only if an I/O-board or a DIG8-board is configured.

**5.4 Register – “Thresholds”**

Configuration of monitoring thresholds for measuring inputs Vdc1, Vdc2, Vdc3, Idc1-3max, temperature and isolation resistance.



Parameter	Value	Unit	Delay (sec)	Hysteresis (%)
<b>Vdc1</b>				
Vmax	57,6	V	1	1
Vwarn	45,6	V	1,90	
Vmin	43,2	V	1,80	5
<b>Vdc2</b>				
Vmax	57,6	V	1	1
Vmin	43,2	V	1	5
<b>Vdc3</b>				
Vmax	28,8	V	1	1
Vmin	21,6	V	1	5
<b>Idc1max</b>				
Idc1max	40,0	A	1	1
<b>Idc2max</b>				
Idc2max	40,0	A	1	1
<b>Idc3max</b>				
Idc3max	40,0	A	1	1
<b>Temperature high</b>				
Temperature high	60,0	°C	1	5
<b>Battery operation</b>				
Battery operation	20,0	A	1	5
<b>Riso error</b>				
Riso error	60	KOhm	1	5


**Vdc1** –  
**Vmax**: over voltage threshold for measuring point Vdc1  
You can put in the value in V or in V/cell. This threshold is used also for controlling of LED “Udc>” on MU1000C front panel.


**Vwarn**: prewarning threshold for measuring point Vdc1  
You can put in the value in V or in V/cell.

**Vmin**: under voltage threshold for measuring point Vdc1  
You can put in the value in V or in V/cell.

**Delay**: delay time for error signalization in sec.

**Hysteresis**: range between error detection start and stop value in % of programmed value





Registered for : Eltek Valere Indust

Signal configuration | Battery | Boost-/ Manual charge / System test | Counter cells | MM1  
 Text | Analog inputs | Digital inputs | **Thresholds** | Devices | Outputs | Modern / RS 232

**Thresholds**

**Vdc1**

Vmax: 57,6 V => 2,40 V/cell Delay: 1 sec. Hysteresis: 1 %  
 Vwam: 45,6 V => 1,90 V/cell  
 Vmin: 43,2 V => 1,80 V/cell Delay: 1 sec. Hysteresis: 5 %

**Vdc2**

Vmax: 57,6 V => 2,40 V/cell Delay: 1 sec. Hysteresis: 1 %  
 Vmin: 43,2 V => 1,80 V/cell Delay: 1 sec. Hysteresis: 5 %

**Vdc3**

Vmax: 28,8 V => 1,20 V/cell Delay: 1 sec. Hysteresis: 1 %  
 Vmin: 21,6 V => 0,90 V/cell Delay: 1 sec. Hysteresis: 5 %

**Idc1max** 40,0 A Delay: 1 sec. Hysteresis: 1 %  
**Idc2max** 40,0 A Delay: 1 sec. Hysteresis: 1 %  
**Idc3max** 40,0 A Delay: 1 sec. Hysteresis: 1 %

Temperature high 60,0 °C Delay: 1 sec. Hysteresis: 5 %  
 Battery operation 20,0 A Delay: 1 sec. Hysteresis: 5 %  
 Riso error 60 KOhm Delay: 1 sec. Hysteresis: 5 %

InterfaceCOM1 OK Cancel 25.6.2008 11:04:19

Vdc2 –

**Vmax**: over voltage threshold for measuring point Vdc2  
 You can put in the value in V or in V/cell.

**Vmin**: under voltage threshold for measuring point Vdc2  
 You can put in the value in V or in V/cell. This threshold is used also for controlling of LED "Udc<" on MU1000C front panel.

**Delay**: delay time for error signalization in sec.

**Hysteresis**: range between error detection start and stop value in % of programmed value

Vdc3 –

**Vmax**: over voltage threshold for measuring point Vdc3  
 You can put in the value in V or in V/cell.

**Vmin**: under voltage threshold for measuring point Vdc3  
 You can put in the value in V or in V/cell.

**Delay**: delay time for error signalization in sec.

**Hysteresis**: range between error detection start and stop value in % of programmed value



MU1000C Configurator Version 1.39.6

Registered for: Eltek Valere Indust

Signal configuration | Battery | Boost-/ Manual charge / System test | Counter cells | MM1  
Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modern / RS 232

Thresholds

**Vdc1**

Vmax: 57,6 V => 2,40 V/cell Delay: 1 sec. Hysteresis: 1 %  
Vwam: 45,6 V => 1,90 V/cell  
Vmin: 43,2 V => 1,80 V/cell Delay: 1 sec. Hysteresis: 5 %

**Vdc2**

Vmax: 57,6 V => 2,40 V/cell Delay: 1 sec. Hysteresis: 1 %  
Vmin: 43,2 V => 1,80 V/cell Delay: 1 sec. Hysteresis: 5 %

**Vdc3**

Vmax: 28,8 V => 1,20 V/cell Delay: 1 sec. Hysteresis: 1 %  
Vmin: 21,6 V => 0,90 V/cell Delay: 1 sec. Hysteresis: 5 %

**Idc1max** 40,0 A Delay: 1 sec. Hysteresis: 1 %  
**Idc2max** 40,0 A Delay: 1 sec. Hysteresis: 1 %  
**Idc3max** 40,0 A Delay: 1 sec. Hysteresis: 1 %

Temperature high 60,0 °C Delay: 1 sec. Hysteresis: 5 %  
Battery operation 20,0 A Delay: 1 sec. Hysteresis: 5 %  
Riso error 60 KOhm Delay: 1 sec. Hysteresis: 5 %


InterfaceCOM1 OK Cancel 25.6.2008 11:04:19

Idc1 – 3  
*Idc1-3max*: over current threshold for measuring point

Temperature high –  
threshold for temperature monitoring inside the cabinet  
(an external connected temperature sensor is required)

*Delay*: delay time for error signalization in sec.  
*Hysteresis*: range between error detection start and stop  
value in % of programmed value

Battery operation –  
threshold for signalization of “Battery discharge  
operation”  
The signal occurs if the measured negative voltage drop  
on battery current shunt exceeds this value.



MU1000C Configurator Version 1.39.6

File Data B5232 Help

Registered for : Eltek Valere Indust

Exit

Signal configuration | Battery | Boost-/ Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modern / RS 232

Thresholds

**Vdc1**

Vmax	57,6	V =>	2,40	V/cell	Delay	1	sec.	Hysteresis	1	%
Vwam	45,6	V =>	1,90	V/cell						
Vmin	43,2	V =>	1,80	V/cell	Delay	1	sec.	Hysteresis	5	%

**Vdc2**

Vmax	57,6	V =>	2,40	V/cell	Delay	1	sec.	Hysteresis	1	%
Vmin	43,2	V =>	1,80	V/cell	Delay	1	sec.	Hysteresis	5	%

**Vdc3**

Vmax	28,8	V =>	1,20	V/cell	Delay	1	sec.	Hysteresis	1	%
Vmin	21,6	V =>	0,90	V/cell	Delay	1	sec.	Hysteresis	5	%

**Idc1max**

	40,0	A	Delay	1	sec.	Hysteresis	1	%
--	------	---	-------	---	------	------------	---	---

**Idc2max**

	40,0	A	Delay	1	sec.	Hysteresis	1	%
--	------	---	-------	---	------	------------	---	---

**Idc3max**

	40,0	A	Delay	1	sec.	Hysteresis	1	%
--	------	---	-------	---	------	------------	---	---

Temperature high

	60,0	°C	Delay	1	sec.	Hysteresis	5	%
--	------	----	-------	---	------	------------	---	---

Battery operation

	20,0	A	Delay	1	sec.	Hysteresis	5	%
--	------	---	-------	---	------	------------	---	---

Riso error

	60	KOhm	Delay	1	sec.	Hysteresis	5	%
--	----	------	-------	---	------	------------	---	---

InterfaceCOM1

OK

Cancel

25.6.2008 11:04:19

*Delay*: delay time for error signalization in sec.

*Hysteresis*: range between error detection start and stop value in % of programmed value

Riso error –

threshold for signalization of “Isolation fault”


The signal occurs if the measured resistance between pluspole and earth or minuspole and earth exceeds this value.

*Delay*: delay time for error signalization in sec.

*Hysteresis*: range between error detection start and stop value in % of programmed value


**5.5 Register – “Devices”**

**5.5.1 Device**




On this page you have to configure the main operation parameter for controlling of connected (via CAN-Bus) power supply modules.


*PSS count* – number of CAN- connected PSS rectifier modules (max. 54)

 This value is used to detect the error state of connected rectifier modules. Every single module in the system has its own CAN address.

Example: If you have 5 units inside of your power supply you have to set the “PSS count” to 5 and the addresses on modules from 1 to 5.

*Redundant PSS count* – number of CAN-connected PSS rectifier modules for redundant operation

 This value is used to detect the error state of



MU1000C Configurator Version 1.39.6

Registered for : Eltek Valere Indust

Signal configuration | Battery | Boost - / Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Device

Rec. count

Inv. count

Redundant Rec. count

Redundant Inv. count

Thyristor count

Fan tray count

I/O - board ☐ yes ☒ no

or ☒ RB6 ☒ DIG18

Mains monit MM1 ☐ yes ☒ no

UNB ☐ yes ☒ no

Temperature sensor1 MU ☐ yes ☒ no

Temperature sensor2 BM1 ☐ yes ☒ no

Temperature sensor3 BM1 ☐ yes ☒ no

Riso measurement ☐ yes ☒ no

Riso reference to ☒ Udc1 ☐ Udc2

Rectifier

Nominal voltage  V =>  V/cell

Battery test voltage  V =>  V/cell

Boost charge voltage  V =>  V/cell

Nominal current  A

Load limit  %

Load limit delay  sec.

Load current difference  %

Current distribution delay  sec.

blink if CAN-Adr. 0 ☐

Thyristor

Voltage 20V =  V

Current 20V =  A

Inv.


Nominal voltage  V

InterfaceCOM1   25.6.2008 11:16:22


redundant connected rectifier modules.  
Every single module in the system has its own CAN address.

Example: If you have 5 units inside of your power supply and you use 4 for load supply + battery charging and 1 module for redundancy operation - you have to set the "PSS count" to 5, the "Redundant PSS count" to 1 and the addresses on modules from 1 to 5.


*INV count* – number of CAN- connected INV inverter modules

 This value is used to detect the error state of connected inverter modules. Every single module in the system has its own CAN address.

Example: If you have 5 units inside of your power supply you have to set the "INV count" to 5 and the addresses on modules from 1 to 5.




*Redundant INV count* – number of CAN-connected INV inverter modules for redundant operation

 This value is used to detect the error state of redundant connected inverter modules. Every single module in the system has its own CAN address.

Example: If you have 5 units inside of your power supply and you use 4 for load supply and 1 module for redundancy operation - you have to set the "INV count" to 4, the "Redundant INV count" to 1 and the addresses on modules from 1 to 5.

*Relay board RK1 or RB6/DIG8* – turn on/off the CAN-connected relay board MU1000C-I/O



MU1000C Configurator Version 1.39.6

File Data RS232 Help

Registered for : Eltek Valere Indust

Exit

Signal configuration | Battery | Boost - / Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Device

Rec. count

Inv. count

Redundant Rec. count

Redundant Inv. count

Thyristor count

Fan tray count

I/O - board ☐ yes ☒ no

or ☒ RB6 ☒ DIG18

Mains monit MM1 ☐ yes ☒ no

UNB ☐ yes ☒ no

Temperature sensor1 MU ☐ yes ☒ no

Temperature sensor2 BM1 ☐ yes ☒ no

Temperature sensor3 BM1 ☐ yes ☒ no

Riso measurement ☐ yes ☒ no

Riso reference to ☒ Udc1 ☐ Udc2

Rectifier

Nominal voltage  V =>  V/cell

Battery test voltage  V =>  V/cell

Boost charge voltage  V =>  V/cell

Nominal current  A

Load limit  %

Load limit delay  sec.

Load current difference  %

Current distribution delay  sec.

blink if CAN-Adr. 0 ☐

Thyristor

Voltage 20V =  V

Current 20V =  A

Inv.

Nominal voltage  V

InterfaceCOM1 OK Cancel 25.6.2008 11:16:22

If you turn on the relay board option you can use the digital input interface on I/O board and on MU1000C hardware to connect external signaling loops. You can use either an I/O board or a RB6 and/or DIG8 board.


**Mains monit. MM1** – turn on/off the CAN-connected mains monitoring board MU1000C-MM

**UNB** – turn on if static bypass switch UNB is also connected to the CAN bus

This feature prevents “Master” collisions on CAN bus.

**Temperature sensor** – turn on/off an external connected active temperature sensor

You need this feature if you want to use temperature compensation of charge voltage or to monitor the cabinet temperature.




The number of the temperature sensors depends on the count of the batteries.  
 (see register "Battery").  
 The picture shows 2 sensors  
 (sensor1 – MU;  
 sensor2 – BM1)

*Riso measurement* – turn on/off the isolation fault monitoring

☞ Turn off if one pole is earthed in the system or if two monitoring units are connected to the same DC bus.


### 5.5.2 INV



Nominal voltage: set the nominal output voltage for the connected inverters




### 5.5.3 Rectifier




**Nominal voltage:** set the nominal charge voltage for the connected rectifier modules.  
 You can put in the value in V or in V/cell.

**Battery test voltage:** set the voltage level for decreasing the rectifier output voltage during battery test


 To secure an uninterruptable load supply you have to set this value higher than battery low threshold of your system. That way the rectifiers are able to take over the load before the battery will disconnected from the load.

You have to turn on the battery test function before this value will have any influence on the system function.


**Boost charge voltage** – set the value for boost charge voltage

 You have to turn on the boost charge function before this value will have any influence on the system function.

**Nominal current** – set the nominal current limitation of the single rectifier module

 Please check the specific data of the used rectifier module type to adjust the correct current limitation.


**Load limit** – pre warning threshold for total rectifier output power



Example: You defined a maximum load on system output of 80% because you do not want that every rectifier operates permanent with 100% output power. The 100% load value will be calculated with number of connected rectifier modules multiplied by max. output current of the single module. If the connected load exceeds the adjusted load limit level the system generates an alarm signal.

*Load limit delay* – delay time for load limitation alarm


*Blink if CAN-ID 0* – enable this value if you want to know whether a module has the CAN address "0"

 This feature is used when you get new modules for system extension. Usually the new modules have the CAN address "0". If you put in all new modules you can see by blinking display that only these modules have to be reprogrammed with a new CAN address.

**5.6 Register – “Outputs”**

On this page you can configure the isolated relay outputs.

**5.6.1 MU1000C**




*Alarm A* - delay time for alarm signalization on relay A


*Alarm B* - delay time for alarm signalization on relay B


*Break/close cont.* – in case of failure the relay contacts are opened/closed

☞ We recommend to include all urgent single alarm signals to alarm A (urgent alarm) and all non urgent alarms to alarm B (non urgent alarm). The alarm configuration will be made in Register “Signal configuration”.

*LED S1/S2* – delay time for LED signalization S1/S2 on MU1000C front panel






 You can set a single failure signalization to LED S1/S2. In that way you are able to expand the front side LED functionality for two additional LED signals.


*Relay K1* - delay time for alarm signalization on relay K1

*Relay K2* - delay time for alarm signalization on relay K2

*Break/close cont.* – in case of failure the relay contacts are opened/closed


 You can use relay K1 and relay K2 on MU1000C to signalize single failures by single relay outputs. It is possible to include more than one single failure to one relay output.


**5.7 Register – "Modem/RS232"**



*RS232* – modem connection is disabled, programming via RS232 cable is possible

*Modem* – programming via RS232 is disabled, modem connection is possible





#### Modem –

*Dial Mode* – set dial mode to pulse or tone dial

*Response to external dial in* – switch on/off the possibility for remote access

*Error messages* – enables the automatic dial back function caused by system faults

*Daily system state report* – the system send every day a state message to a predefined phone number; time is adjustable

*Ring detect dial back* – enables the automatic dial back function after receiving a call (higher security than direct remote dial in)

*Phone number* – set the phone number for automatic dial back function

*Error message delay time* – delay time for error

MU1000C Configurator Version 1.39.6  
File Data B5232 Help

Registered for : Eltek Valere Indust

Signal configuration | Battery | Boost-/ Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Data transmission

☒ Modem ☐ RS 232

IP - Address: 192 . 168 . 1 . 1

Dial mode  
☒ Pulse ☐ Tone

☐ Response to external dial-in  
☐ Error messages  
☐ Daily system state report at  
☐ Ring detect dial back

Telephonenumber: 0

Error message delay time: 1 min.

Station identification: Station 1

Password: CONVERTRONIC

Modem init. string: AT AT%O AT&F %dATX3E0L1S0=0

InterfaceCOM1 OK Cancel 25. 6. 2008 12:26:36


signalization by automatic dial back in minutes

This delay time is used to prevent automatic system dial back caused by short non permanent error messages.

Station identification – fill in a name for the station; the name will be transmitted during modem connection

Password – fill in a password for remote access

Modem init string – fill in a specific modem init string for the used modem  
Do not change the factory setting for preconfigured systems!



MU1000C Configurator Version 1.39.6

File Data RS232 Help

Registered for : Eltek Valere Indust

Exit

Signal configuration | Battery | Boost -/ Manual charge / System test | Counter cells | MM1

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Data transmission

☒ Modem ☐ RS 232

IP - Address

192 . 168 . 1 . 1

Dial mode

☒ Pulse ☐ Tone

☐ Response to external dialIn

☐ Error messages

☒ Daily system state report at 00 : 00 hh:mm

☐ Ring detect dial back

weekday

☒ Monday  
☒ Tuesday  
☒ Wednesday  
☒ Thursday  
☒ Friday  
☒ Saturday  
☒ Sunday

Telephonenumber 0

Error message delay time 1 min.

Station identification Station 1

Password CONVERTRONIC


Modem init. string AT AT%O AT&F %dATX3E0L1S0=0

InterfaceCOM1 OK Cancel 25. 6.2008 12:28:02

*Daily system state report at – time adjustment:  
set week, days and time (hour/minutes)*




## 5.8 Register – "Signal configuration"




On this page you can assign every single failure signal in the system to one or more output channels. Click in the row of output device you want to add a fault signal. The actual fault signal is marked in red. The black sign shows that the fault is enabled on this output device.

*Error state* – assign a single error to error state list on MU1000 display

*Event history* – assign a single fault to MU1000C event history list

 The event history show time and date when the fault occurs and time and date when the fault is gone. The event history is a memory stack for 100 messages. If the stack limit is reached the oldest message will be erased.

*LED S1/S2* – assign a single fault to front side LED S1/S2



*Alarm A/B* – assign a single fault to alarm relay K4/K3 on MU1000C hardware

*Relay K1/K2* – assign a single fault to alarm relay K1/K2 on MU1000C hardware


*Relay K11-K18* – assign a single fault to alarm relay K11-K18 on MU1000C-I/O board (optional board have to be connected on CAN bus)

*Modem* – assign a single fault to modem (fault messages will be sent during remote access by modem)

All fault signals are OR-operation.

## 5.9 Register – "Battery"

### 5.9.1 Value



**Battery count** – number of monitored battery banks

If you connect the optional MU1000C-BM board to monitor a second or third battery bank with MU1000C you have to increase this value to the number of monitored banks.

By changing the number of battery banks the number of BM-sockets in the register "Analog inputs" will change.

**Cell count** – number of installed battery cells of each bank

**Tapping point** – number of cells where the tapping point for battery unsymmetric voltage measurement is connected (counted from minus side)

**Nominal capacity 1/2/3** – nominal battery capacity of bank 1/2/3

MU1000C Configurator Version 1.39.6

Registered for : Eltek Valere Indust

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Signal configuration | Battery | Boost - / Manual charge / System test | Counter cells | MM1

Value

Battery count 2

Cell count 24 tapping point (from -) 12

Nominal capacity 1 50 Ah

Max. charge current 1 30,0 A

Nominal capacity 2 50 Ah

Max. charge current 2 30,0 A

Nominal capacity 3 50 Ah

Max. charge current 3 30,0 A

Battery unsymmetry 2,5 V Delay 1 sec.

Hysteresis 10 %

Battery current control

rectifier voltage increase delay 0 sec.

rectifier voltage decrease delay 0 sec.

Test

Min. discharge voltage 40,0 V

Max. discharge capacity 80 %

Max. test-duration 04:00 hh:mm

☐ Manual test enabled ☐ Boost charge after test

☐ Automatic test enabled Start test digit input 0

Tk

Tk -2 mV/(Cell \* K)

Tk min 0 °C

Tk max 60,0 °C

InterfaceCOM1 OK Cancel 25.6.2008 11:29:51

*Max. charge current* – value for charging current limitation of bank 1/2/3


*Battery asymmetry* – Value for maximal voltage deviation between both block sides of battery

☞ This value should be higher than voltage of one battery cell.

*Delay* – delay time for unsymmetric fault signalization in sec.

*Hysteresis* – value between fault detection and fault deleting in % of programmed battery unsymmetry value

### 5.9.2 Test



*Min. discharge voltage* – battery low threshold for battery test

*Max. discharge capacity* – maximal discharge capacity in % of nominal battery capacity

*Max. test duration* – maximal battery test time in hour:minutes


*Manual test enable* – enables the possibility to start the battery manual via front side keys

*Automatic test enable* – enables the automatic battery test function

*Test start at* – date of first battery test (year/month/day and hour/min)

*Repetition* – interval for new battery tests beginning from first test date (in days)

### 5.9.3 Tk




The screenshot shows the MU1000C Configurator Version 1.39.6 software. The 'Battery' tab is selected. The 'Value' section contains fields for Battery count (2), Cell count (24), tapping point (from -) (12), Nominal capacity 1 (5.0 Ah), Max. charge current 1 (30.0 A), Nominal capacity 2 (5.0 Ah), Max. charge current 2 (30.0 A), Nominal capacity 3 (5.0 Ah), Max. charge current 3 (30.0 A), Battery unsymmetry (2.5 V), Delay (1 sec), Hysteresis (10 %), and Battery current control (rectifier voltage increase delay 0 sec, rectifier voltage decrease delay 0 sec). The 'Test' section contains fields for Min. discharge voltage (40.0 V), Max. discharge capacity (80 %), Max. test-duration (04:00 hh:mm), Manual test enabled (unchecked), Boost charge after test (unchecked), Automatic test enabled (unchecked), and Start test digit input (0). The 'Tk' section contains fields for Tk (-2 mV/(Cell \* °K)), Tk min (0 °C), and Tk max (60.0 °C). The bottom status bar shows 'InterfaceCOM1', 'OK', 'Cancel', and the date/time '25.6.2008 11:29:51'.

With these values you can have influence on the charge line characteristic (inclination, start/stop temperature for temperature compensation).

*Tk* – temperature coefficient for temperature compensation of charge voltage  
 Put in the value without sign ("4" means "-4" mV/cell/K).


*Tk min* – minimum temperature for temperature compensation of charge voltage

*Tk max* – maximum temperature for temperature compensation of charge voltage

 If temperature of battery is out of the defined range the temperature compensation is switched off. Also during boost charge the temperature compensation is switched off.

## 5.10 Register – “Boost-/Manual charge/System test”

### 5.10.1 Boost charge



**Boost charge**

Manual boost charge enabled ☒

Automat. boost charge enabled ☐

Aut. boost charge starts below 43,2 V  
 or Ibatt (Idc1) > 250 A  
 after a delay of 2 sec.  
 Battery operation / mains fault 1 min.

Boost charge dis. digital input 0

Boost charge start digital input 0

Boost charge max. time 1 h

follow-up charge starts above 56,0 V  
 or Ibatt (Idc1) < 30 A  
 after a delay of 1 sec.  
 follow-up charge duration 1 min.

Fan delay 5 min.

**Manual charge**

Activation enabled ☐

Over voltage alarm enabled ☐

Alarm delay after manual charge 600 sec.

Vmax 65,0 V => 2,71 V/cell

Max. charging current 40,0 A

Emerg. switch off : Vmax + 3,5 V

**System test**

Activation enabled ☐

Over voltage alarm enabled ☐

Alarm delay after system test 600 sec.

Vmin 20,0 V => 0,83 V/cell

Vmax 80,0 V => 3,33 V/cell

Max. charging current 50,0 A

InterfaceCOM1 OK Cancel 25.6.2008 11:33:20


**Manual boost charge enabled** – enables the possibility to start battery boost charging function manually via front side keys


**Automat. boost charge enabled** – enables the automatic boost charging function  
 (reasons to start boost charge automatically: battery voltage low and/or mains fault)

**Aut. Boost charge starts below** – minimum battery voltage level where automatic boost charge starts

**After a delay of** – delay time for start boost charge after voltage level was reached

**Battery operation/Mains fault** – maximal time duration for mains failure or battery operation to start boost charging automatically





The screenshot shows the 'MU1000C Configurator Version 1.39.6' window with the 'Battery' tab selected. The interface is divided into several sections for configuring battery-related parameters.

**Boost charge**

- ☒ Manual boost charge enabled
- ☐ Automat. boost charge enabled
- Aut. boost charge starts below: 43,2 V
- or Ibatt (Idc1) >: 250 A
- after a delay of: 2 sec.
- Battery operation / mains fault: 1 min.
- Boost charge dis. digital input: 0
- Boost charge start digital input: 0
- Boost charge max. time: 1 h
- follow-up charge starts above or Ibatt (Idc1) <: 56,0 V
- 30 A
- after a delay of: 1 sec.
- follow-up charge duration: 1 min.
- Fan delay: 5 min.

**Manual charge**

- ☐ Activation enabled
- ☐ Over voltage alarm enabled
- Alarm delay after manual charge: 600 sec.
- Vmax: 65,0 V => 2,71 V/cell
- Max. charging current: 40,0 A
- Emerg. switch off : Vmax + : 3,5 V

**System test**

- ☐ Activation enabled
- ☐ Over voltage alarm enabled
- Alarm delay after system test: 600 sec.
- Vmin: 20,0 V => 0,83 V/cell
- Vmax: 80,0 V => 3,33 V/cell
- Max. charging current: 50,0 A

The bottom of the window shows a status bar with 'InterfaceCOM1', 'OK', 'Cancel', and a timestamp '25.6.2008 11:33:20'.

**Boost charge inhibit –**

By activating this item you can choose the input to cut off fast

**Follow-up charge starts above –** battery voltage level where follow-up charging time will start


**After a delay of –** delay time for start follow-up charging time after boost charge end voltage level was reached

**Follow-up charge duration –** duration time for follow-up charging (in minutes)

**Fan delay –** delay time for battery room ventilation fan (an external fan has to be connected to an outgoing alarm relay for this function)



### 5.10.2 Manual charge



The screenshot shows the 'MU1000C Configurator Version 1.39.6' window. The 'Manual charge' tab is selected under the 'Boost - / Manual charge / System test' category. The interface is divided into three main sections: Boost charge, Manual charge, and System test.

**Boost charge section:**

- ☒ Manual boost charge enabled
- ☐ Automat. boost charge enabled
- Aut. boost charge starts below: 43,2 V
- or Ibatt (Idc1) >: 250 A
- after a delay of: 2 sec.
- Battery operation / mains fault: 1 min.
- Boost charge dis. digital input: 0
- Boost charge start digital input: 0
- Boost charge max. time: 1 h
- follow-up charge starts above: 56,0 V
- or Ibatt (Idc1) <: 30 A
- after a delay of: 1 sec.
- follow-up charge duration: 1 min.
- Fan delay: 5 min.

**Manual charge section:**

- ☐ Activation enabled
- ☐ Over voltage alarm enabled
- Alarm delay after manual charge: 600 sec.
- Vmax: 65,0 V => 2,71 V/cell
- Max. charging current: 40,0 A
- Emerg. switch off : Vmax + 3,5 V

**System test section:**

- ☐ Activation enabled
- ☐ Over voltage alarm enabled
- Alarm delay after system test: 600 sec.
- Vmin: 20,0 V => 0,83 V/cell
- Vmax: 80,0 V => 3,33 V/cell
- Max. charging current: 50,0 A

At the bottom, there are buttons for 'InterfaceCOM1', 'OK', and 'Cancel', along with a timestamp '25.6.2008 11:33:20'.

*Activation enabled* – enables the possibility to start manual charge with front side keys

*Over voltage alarm enabled* – possibility to disable the over voltage alarm if the voltage level is reached due to manual charging


*Alarm delay after manual charge* – time to give a reminding alarm to the user after manual charge have been started (to avoid over charging of the battery in case that the user has forgotten to switch off manual charging)

*Vmax* – maximal allowed charging voltage

*Max. charging current* – maximal battery charging current during manual charge operation

*Emerg. Switch off* – not used

### 5.10.3 System test



This function can be used to test all monitoring thresholds of the system during commissioning.

**Activation enabled** – enables the possibility to start system test with voltage variation function

**Over voltage alarm enabled** – possibility to disable the over voltage alarm if voltage level is reached due to manual system test.


**Alarm delay after manual charge** – time to give a reminding alarm to the user after system test have been started (to avoid that system operates permanent in wrong mode in case that the user has forgotten to switch off system test)

**Vmin** – minimal allowed system test voltage

**Vmax** – maximal allowed system test voltage

**Max. charging current** – maximal battery charging current during system test operation

### 5.11 Register – “Counter cell”



MU1000C Configurator Version 1.39.6

Registered for : Eltek Valere Indust

Text | Analog inputs | Digital inputs | Thresholds | Devices | Outputs | Modem / RS 232

Signal configuration | Battery | Boost -/ Manual charge / System test | Counter cells | MM1

Counter cells

on off

Counter cell 1 60.0 V 58.5 V

Counter cell 2 61.0 V 59.5 V

Voltage reference

☒ Vdc1 ☐ Vdc2 ☐ Vdc3

InterfaceCOM1 OK Cancel 25.6.2008 11:34:48

On this page you can configure the values for switching a one-level or two-level counter cell. For this function one or two external contactors have to be connected to outgoing alarm relays. The counter cell function has to be assigned in signal configuration menu to the used alarm relays.


#### Counter cells-

*Counter cell 1* – voltage value for open (on) and close (off) the dropping diode contactor 1

*Counter cell 2* – voltage value for open (on) and close (off) the dropping diode contactor 2

*Voltage reference* – sets the measuring input that is used to measure the reference voltage

### 5.12 Register – “MM1”



Configuration of the optional CAN connected mains monitoring board MU1000C-MM.

**MM1 –**

**Monitoring L1/L2/L3** – enables the monitoring channel for phase L1. L2, L3


**V>** - monitoring threshold mains voltage high alarm in % of measuring value

**V<** - monitoring threshold for mains voltage low alarm in % of measuring value

**Delay** – delay time for mains fault detection

**Display** – enables the display for measured voltage and/or current value of all enabled phases

## 6. Send new data to MU1000C




If you finished the configuration on all register entrees, you have to send the new data to MU1000C.

Select *File/Data/Write PC->MU1000C...*

If any error occurs please try to start the transmission again.


## 7. Save project file



To save the changed project file select *File/Save...*

To save the new generated project file select *File/Save as...*, search for right subdirectory on your harddisk, put in a new file name and confirm with "OK".

## 8. Input LCD characters (especial for cyrillic characters)




There is the possibility to key in specific LCD characters in different text fields, as for example in the *Logo line 1* and 2, in *Analog inputs* or *Digital inputs* (see section 8.1.).


Press the right mouse key in the respective text field. After that there appears a Popup menu with the choice of "LCD character" and "paste".

With the choice of "LCD character" a form appears such as shown at section 8.1. (see the following page).

It is possible to key in a maximum of 16 characters. These characters appear in the edit field below. Click on *Copy* to load the required character(s) into the buffer, leave the form with *Exit* and copy this into the text field with another click on the right mouse key choosing *Paste*.



**8.1. LCD character set**



The picture on the left shows the especial LCD character set.



**9. Notes**

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

## 10. Data transmission Error / Data transmission abortion

### Transmission Error:

On display	Error	Error probability	
"Transmission Error No answer from the MU1000C"	Communication error	The MU1000C is not switched on	The MU1000C switch on
		The MU1000C is in the menu (to push on the Enter-button) communication is not possible	Leave the menu by pressing the ESC-button
		Read/write-error: the MU1000C is in timeout	Wait until timeout is over (display)
		Chose wrong interface	Check the interface in the menu RS232/com
		Interface connection defect ( Hardware)	Check the communication between PC and MU1000C
"Checksum error"	Check sum	Data transmission failed	

### Transmission abortion:

Pressing the abort button during the data transmission

### Transmission abortion during the write cycle:

**Important:** The MU1000C lost their new values during the transmission time. At this point the MU1000C gets internal default values. At this time you have to repeat the write cycle.